

Cut drywall on this solid line

Cut drywall on this solid line
16.5 inches wide

Quick Install Guide - Standard Grill

For more details see Installation Manual

- 1) Select location for In-Wall installation
- 2) Unpack both cartons
- 3) Locate edge of 2" x 4" studs
(Note: Designed for 16" on center spacing)
- 4) Attach template to wall
- 5) Cut out drywall per template
- 6) Assemble back box to driver module
- 7) Route wire into opening
- 8) Install In-Wall assembly into opening
- 9) Connect wire
- 10) Install drywall per template
- 11) Finish wall (tape, mud, texture and paint)
- 12) Remove protective cover on driver
- 13) Install Standard Grill

Velodyne

**SC-IW Installation Template
For Use with Standard Grill**

www.velodyne.com

345 Digital Drive
Morgan Hill, CA 95037
408.465.2800

88-SCIWS Rev A

31.25 inches

Grill Opening Height
(reference)

Negative
(black)
speaker
wire

Positive
(red)
speaker
wire

Edge of stud
(14.5 inch spacing)

Center of stud
(16 inches on center)

Center line

13 inches
Grill Opening
(reference)

5.375 inches

16.5 inches

Cut drywall on this solid line

STUD

STUD